

# PeraSpray RTU

Ready-to-Use Peracetic Acid Sanitizer

Product Code: I03064



**IRRITANT**

PeraSpray RTU is suitable for use in food and beverage processing facilities, including federally inspected meat and poultry plants.

PeraSpray RTU delivers the power of the peracetic acid in a ready to use formula. It is an ideal replacement for iodine or rubbing alcohol as a sanitizer for miscellaneous parts. PeraSpray is also included on EPA's List N.

- 170 PPM Peracetic Acid as supplied
- Shelf life greater than one year
- Non-flammable
- Quat free
- Certified Organic and Kosher
- Kills 99.99% of bacteria and viruses
- Non-toxic and biodegradable
- Phosphate free

Available in 55-gallon drums, 5-gallon pails, and case of 12 1-quart bottles with trigger sprays.

## USAGE DIRECTIONS

**To Sanitize Hard, Non-porous Food Contact Surfaces:** Spray until thoroughly wet. Let stand 60 seconds before wiping. For heavily soiled areas, precleaning is required. Drain any excess solution. Do not rinse.

**To Disinfect:** Spray until thoroughly wet. Let stand 10 minutes then wipe. For heavily soiled areas, precleaning is required.

## SAFETY AND HAZARDS

**Hazard Statements:** May cause skin irritation and eye irritation.

### Precautionary Statements: Response

**IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses if present and easy to do. Continue rinsing.

**IF ON SKIN:** Rinse with lukewarm, gentle-flowing water for 5 minutes or until product is removed. Call a POISON CENTER or doctor if you feel unwell.

**IF INGESTED:** Get medical advice / attention if you feel unwell or are concerned.

**PRODUCT CLASS:** Disinfectant / Sanitizer

### Most Important Symptoms and Effects:

Contact with eye can cause irritation. Contact with skin can cause irritation.

### Indication of Immediate Medical Attention and Special Treatment Needed:

Treat symptomatically.

## PROTECTIVE EQUIPMENT

### Precautionary Statements: Prevention

Wear eye protection. Wear gloves when contacting spray directly.



SAFETY GLASSES



SAFETY GLOVES

# PeraSpray RTU

Product Code: I03064

**IRRITANT**

## DILUTION CHART AND TEST KIT

Application	Dilution Rate
Sanitizing / Disinfecting Applications	Use without dilution

## TECHNICAL INFORMATION

Form..... Liquid  
Color ..... Clear  
Odor ..... Vinegar  
pH @ 1%..... 1.8 - 2.2  
Foam ..... Minimal  
Biodegradable ..... Yes  
Phosphates..... None  
Density ..... 1.00

## DOT SHIPPING NAME

Non-hazardous material.

## EPA REGISTRATION

EPA Reg. No. 63838-15  
EPA Est. No. 63838-CA-01: 63838-AR-001

Peraspray is included on EPA's List N and meets the criteria to make claims against certain emerging viral pathogens from the following viral categories:

- Enveloped viruses
- Large Non-Enveloped Viruses

Peraspray has demonstrated effectiveness against viruses similar to SARS-CoV-2 on hard, non-porous surfaces. Therefore, Peraspray can be used against SARS-CoV-2 when used in accordance with the directions for use against Human Rhinovirus 42 ATCC VR338 on hard, non-porous surfaces. Refer to the CDC website for additional information.

MANUFACTURED BY



Birko Corporation  
9152 Yosemite Street  
Henderson, CO 80640  
800.525.0476

[www.birkocorp.com](http://www.birkocorp.com)